

Fast Ethernet PCI Adapter with Firewall Protection

User Guide

SMC1255TX



Barricade PCI User Guide

From SMC's Barricade line of award-winning workgroup LAN solutions

SMC[®]

Networks

38 Tesla

Irvine, CA 92618

Phone: (949) 679-8000

December 2002

Pub. No: 150000026800A

Part No: 01-111337-006

Copyright

Information furnished by SMC Networks, Inc. (SMC) is believed to be accurate and reliable. However, no responsibility is assumed by SMC for its use, nor for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of SMC. SMC reserves the right to change specifications at any time without notice.

Copyright © 2002 by
SMC Networks, Inc.
38 Tesla
Irvine, CA 92618

All rights reserved. Printed in Taiwan

Trademarks:

SMC is a registered trademark; and EZ Networking is a trademark of SMC Networks, Inc. Other product and company names are trademarks or registered trademarks of their respective holders.

LIMITED WARRANTY

Limited Warranty Statement: SMC Networks, Inc. ("SMC") warrants its products to be free from defects in workmanship and materials, under normal use and service, for the applicable warranty term. All SMC products carry a standard 90-day limited warranty from the date of purchase from SMC or its Authorized Reseller. SMC may, at its own discretion, repair or replace any product not operating as warranted with a similar or functionally equivalent product, during the applicable warranty term. SMC will endeavor to repair or replace any product returned under warranty within 30 days of receipt of the product.

The standard limited warranty can be upgraded to a Limited Lifetime* warranty by registering new products within 30 days of purchase from SMC or its Authorized Reseller. Registration can be accomplished via the enclosed product registration card or online via the SMC Web site. Failure to register will not affect the standard limited warranty. The Limited Lifetime warranty covers a product during the Life of that Product, which is defined as the period of time during which the product is an "Active" SMC product. A product is considered to be "Active" while it is listed on the current SMC price list. As new technologies emerge, older technologies become obsolete and SMC will, at its discretion, replace an older product in its product line with one that incorporates these newer technologies. At that point, the obsolete product is discontinued and is no longer an "Active" SMC product. A list of discontinued products with their respective dates of discontinuance can be found at:

http://www.smc.com/index.cfm?action=customer_service_warranty.

All products that are replaced become the property of SMC. Replacement products may be either new or reconditioned. Any replaced or repaired product carries either a 30-day limited warranty or the remainder of the initial warranty, whichever is longer. SMC is not responsible for any custom software or firmware, configuration information, or memory data of Customer contained in, stored on, or integrated with any products returned to SMC pursuant to any warranty. Products returned to SMC should have any customer-installed accessory or add-on components, such as expansion modules, removed prior to returning the product for replacement. SMC is not responsible for these items if they are returned with the product.

LIMITED WARRANTY

Customers must contact SMC for a Return Material Authorization number prior to returning any product to SMC. Proof of purchase may be required. Any product returned to SMC without a valid Return Material Authorization (RMA) number clearly marked on the outside of the package will be returned to customer at customer's expense. For warranty claims within North America, please call our toll-free customer support number at (800) 762-4968. Customers are responsible for all shipping charges from their facility to SMC. SMC is responsible for return shipping charges from SMC to customer.

WARRANTIES EXCLUSIVE: IF AN SMC PRODUCT DOES NOT OPERATE AS WARRANTED ABOVE, CUSTOMER'S SOLE REMEDY SHALL BE REPAIR OR REPLACEMENT OF THE PRODUCT IN QUESTION, AT SMC'S OPTION. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND ARE IN LIEU OF ALL OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, EITHER IN FACT OR BY OPERATION OF LAW, STATUTORY OR OTHERWISE, INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. SMC NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME FOR IT ANY OTHER LIABILITY IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE OR USE OF ITS PRODUCTS. SMC SHALL NOT BE LIABLE UNDER THIS WARRANTY IF ITS TESTING AND EXAMINATION DISCLOSE THE ALLEGED DEFECT IN THE PRODUCT DOES NOT EXIST OR WAS CAUSED BY CUSTOMER'S OR ANY THIRD PERSON'S MISUSE, NEGLIGENCE, IMPROPER INSTALLATION OR TESTING, UNAUTHORIZED ATTEMPTS TO REPAIR, OR ANY OTHER CAUSE BEYOND THE RANGE OF THE INTENDED USE, OR BY ACCIDENT, FIRE, LIGHTNING, OR OTHER HAZARD.

LIMITATION OF LIABILITY: IN NO EVENT, WHETHER BASED IN CONTRACT OR TORT (INCLUDING NEGLIGENCE), SHALL SMC BE LIABLE FOR INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY KIND, OR FOR LOSS OF REVENUE, LOSS OF BUSINESS, OR OTHER FINANCIAL LOSS ARISING OUT OF OR IN CONNECTION WITH THE SALE, INSTALLATION, MAINTENANCE, USE, PERFORMANCE, FAILURE, OR INTERRUPTION OF ITS PRODUCTS, EVEN IF SMC OR ITS AUTHORIZED RESELLER HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

SOME STATES DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES OR THE LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES FOR CONSUMER PRODUCTS, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, WHICH MAY VARY FROM STATE TO STATE. NOTHING IN THIS WARRANTY SHALL BE TAKEN TO AFFECT YOUR STATUTORY RIGHTS.

* SMC will provide warranty service for one year following discontinuance from the active SMC price list. Under the limited lifetime warranty, internal and external power supplies, fans, and cables are covered by a standard one-year warranty from date of purchase.

SMC Networks, Inc.
38 Tesla
Irvine, CA 92618

COMPLIANCES

FCC - Class B

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with instructions, may cause harmful interference to radio communications. However, there is no guarantee that the interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or an experienced radio/TV technician for help

FCC Caution: To assure continued compliance, (example - use only shielded interface cables when connecting to computer or peripheral devices). Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

CAUTION STATEMENT: FCC Radiation Exposure Statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 cm (8 in) between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

VCCI Class B Compliance (Japan)

この装置は、情報処理装置等電波障害自主規制協議会（VCCI）の基準に基づくクラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると受信障害を引き起こすことがあります。

取り扱い説明書に従って正しい取り扱いをして下さい。

EC Conformance Declaration - Class B

SMC contact for these products in Europe is:

SMC Networks Europe,
Edificio Conata II,
Calle Frutuós Gelabert 6-8, 2^o, 4^a,
08970 - Sant Joan Despí,
Barcelona, Spain.

This information technology equipment complies with the requirements of the Council Directive 89/336/EEC on the Approximation of the laws of the Member States relating to Electromagnetic Compatibility and 73/23/EEC for electrical equipment used within certain voltage limits and the Amendment Directive 93/68/EEC. For the evaluation of the compliance with these Directives, the following standards were applied:

- RFI Emission:
- Limit class B according to EN 55022: 1998
 - Limit class A for harmonic current emission according to EN 61000-3-2: 1995
 - Limitation of voltage fluctuation and flicker in low-voltage supply system according to EN 61000-3-3: 1995
- Immunity:
- Product family standard according to EN 55024: 1998
 - Electrostatic Discharge according to EN 61000-4-2: 1995 (Contact Discharge: ± 4 kV, Air Discharge: ± 8 kV)
 - Radio-frequency electromagnetic field according to EN 61000-4-3: 1996 (80 - 1000 MHz with 1 kHz AM 80% Modulation: 3 V/m)
 - Electrical fast transient/burst according to EN 61000-4-4: 1995 (AC/DC power supply: ± 1 kV, Data/Signal lines: ± 0.5 kV)
 - Surge immunity test according to EN 61000-4-5: 1995 (AC/DC Line to Line: ± 1 kV, AC/DC Line to Earth: ± 2 kV)
 - Immunity to conducted disturbances, Induced by radio-frequency fields: EN 61000-4-6: 1996 (0.15 - 80 MHz with 1 kHz AM 80% Modulation: 3 V/m)
 - Power frequency magnetic field immunity test according to EN 61000-4-8: 1993 (1 A/m at frequency 50 Hz)
 - Voltage dips, short interruptions and voltage variations immunity test according to EN 61000-4-11: 1994 (>95% Reduction @ 10 ms, 30% Reduction @ 500 ms, >95% Reduction @ 5000 ms)
- LVD:
- EN 60950 (A1/1992; A2/1993; A3/1993; A4/1995; A11/1997)

Warning: Do not plug a phone jack connector in the RJ-45 port. This may damage this device.

TABLE OF CONTENTS

Introduction	1
Features and Benefits	2
Hardware Description	3
LED Indicators	4
Remote LAN Wakeup	5
Installation	6
Equipment Checklist	6
Hardware Installation	7
Driver Installation	9
Software Installation	13
EtherGuard	17
WiNeTool	23
Configuration	24
Send Packet	26
Packet Generator	27
Send ACPI Packet	28
Receive Packet - Gauge	29
Capture Console Toolbar	30
Filter Setting - MAC Address	31
Filter Setting - IP Address	32
Filter Setting - Protocol	32
Filter Setting - Pattern	33
Filter Setting - Buffer Size	33
Packet Analysis	34
Receive Packet - Detail	35

TABLE OF CONTENTS

Troubleshooting36

 PCI Compatibility 36

 Solutions for Common Problems 38

 Network Card Installation Problems 38

 Network Connection Problems 39

Cable Specifications41

 Cable and Specifications 41

 Twisted-Pair Cable and Pin Assignments 41

Specifications43

INTRODUCTION

SMC's Barricade PCI, SMC1255TX, is a dual-speed Fast Ethernet card for PCI local bus-compliant computers. A true plug-and-play device, this card is auto-configurable upon power up and also supports auto-negotiation to automatically select the optimum speed and communication mode of an attached device. This Barricade PCI complies with ACPI and OnNow PC98/PC99 and also supports Remote LAN Wakeup. By connecting the Barricade PCI card's Wake-On-LAN (WOL) cable, a WOL-enabled computer can be managed remotely. Software can be loaded and updated, configurations changed, data backed up and inventory checked, all from a central location. See "Remote LAN Wakeup" on page 5 for more information.

The Barricade PCI card also provides SMC EtherGuard (personal firewall) and WiNeTool (personal sniffer tool) features and benefits. SMC EtherGuard prevents children/employees from visiting specified Web sites. It also automatically blocks Trojan Horses. WiNeTool allows you to monitor and analyze network traffic.

Features and Benefits


- Compatible with IEEE 802.3 Ethernet and IEEE 802.3u Fast Ethernet standards
- Auto-negotiation selects 10/100 Mbps and full/half duplex for up to 200 Mbps of bandwidth
- Automatic configuration using the computer's BIOS setup program
- Supports Remote LAN Wakeup for efficient centralized desktop management
- Supports optional boot ROM for remote booting
- ACPI and OnNow/PC98/99 compliance reduces power consumption
- SMC EtherGuard personal firewall and WiNeTool personal sniffer tool features and benefits

Hardware Description

The Barricade PCI is equipped with:


- 1 RJ-45 connector for 10/100 Mbps connections
- 1 3-pin connector for Wake-On-LAN cable
- 1 Socket for optional boot ROM
- 1 LED indicator

The components of the Barricade PCI are shown in the figure below:



LED Indicators

The Barricade PCI includes one status LED indicator, as described in the following figure and table.



Status	Color	Description
On	Amber	Indicates a valid 10BASE-T link
Flashing		Indicates 10 Mbps network activity
On	Green	Indicates a valid 100BASE-TX link
Flashing		Indicates 100 Mbps network activity

Remote LAN Wakeup

Remote LAN Wakeup capability is a key feature of a centrally managed PC environment. This technology enables networked PCs to be “woken up” from a sleep or powered-off state so they can be managed from a central location, at any time of the day or night.

To employ Remote LAN Wakeup, three elements are required:

- Desktop management software that can send a “wake-up” packet to a PC.
- A Wake-On-LAN enabled PC motherboard that can supply low-level auxiliary power to a network card when the PC is powered off.
- A Wake-On-LAN network card that can recognize a wake-up packet and signal the PC to power up.

A Wake-On-LAN enabled PC is never completely powered off, it maintains a low-level auxiliary power supply to the motherboard. The 3-wire Wake-On-LAN cable provides one line for the network card auxiliary power and one line for the card wake-up signal, the other line is ground.

Even if the PC is powered off, the network card is always active and monitoring the network. When a wake-up packet is detected, the card signals the motherboard to power up the PC. With the PC powered on, maintenance and other support tasks can be performed.

INSTALLATION

Equipment Checklist

After unpacking the Barricade PCI card, check the contents of the box to be sure you have received the following components:

- Barricade PCI card SMC1255TX
- Wake-On-LAN cable
- One CD with:
 - Drivers for the SMC Barricade PCI Adapter
 - EtherGuard Firewall Software
 - WiNeTool Utility
- SMC Warranty Registration Card
- This User Guide


Immediately inform your dealer in the event of any incorrect, missing, or damaged parts. If possible, please retain the carton and original packing materials in case there is a need to return the product.

Please fill out and return the Warranty Registration Card to SMC or register on SMC's Web site. The Barricade PCI card is covered by a limited lifetime warranty.


Hardware Installation

Network cards are sensitive to static electricity. To protect the card, avoid touching its electrical components and always touch the metal chassis of your computer before handling the card.

1. Switch off the computer, unplug the power cord, and remove the computer's cover.
2. Select an unused PCI bus master slot and remove its protective bracket.
3. Carefully insert the card and press until all the edge connectors are firmly seated inside the slot. Then screw the card's bracket securely into the PC's chassis.



4. Attach the Wake-On-LAN cable (optional). If you require Wake-On-LAN capability from a powered-off state, attach one end of the 3-pin Wake-On-LAN cable to the connector on the top edge of the card, and the other end to the “5 V Standby” connector on the computer’s motherboard. Refer to your computer’s installation manual to locate this connector.



5. Connect the Barricade PCI card directly to a 10BASE-T or 100BASE-TX hub or switch using UTP cable (Category 3, 4, or 5 for 10BASE-T; Category 5 for 100BASE-TX). The maximum allowable length of UTP cable connections is 100 meters (328 ft). When inserting an RJ-45 plug, be sure the tab on the plug clicks into position to ensure that it is properly seated.
6. Replace the computer’s cover and power it on. The Barricade PCI card should be automatically configured by the host computer’s BIOS. However, if you have an older computer, you may have to manually configure the computer’s BIOS settings. See “Troubleshooting” on page 36.

Driver Installation


The SMC CD-ROM that accompanies the Barricade PCI card contains all the network operating system drivers supported by this card. Please read the “RELEASE.TXT” file on the CD for a list of all drivers. Also, a text file is included with each driver to detail the proper installation procedure. Any new or updated drivers can be downloaded from SMC’s Web site.

http://www.smc.com/index.cfm?action=tech_support_drivers_downloads


1. Windows will automatically detect the new hardware and prompt you to install the driver. Click “Next.”




2. Click “Next.”




3. Check “Specify a location,” and click “Next.”



4. Insert the attached CD-ROM into your CD drive, and type E:\ (assuming E: is the location of your CD drive), click “Browse.”




5. On the CD-ROM, choose the folder for your operating system. Then click “Open.”



6. Click “OK” to install the driver.



7. A “Digital Signature Not Found” screen will warn you that the software does not contain a Microsoft digital signature and ask you if you wish to continue the installation. Click “Yes.”
8. On the “Completing the Found New Hardware Wizard” screen, click “Finish” to complete the driver installation.



9. The “System Settings Change” box may ask you to restart the computer. If so, click “Yes.”

Software Installation

EtherGuard is a Personal Firewall that guards your computer, your children, your employees, and yourself against network and Internet intrusions.


WiNeTool provides network adapter information, generates specified packets, captures packets, and analyses network traffic.

Both the EtherGuard and WiNeTool software installation procedure is the same. The screens shown here are for the EtherGuard program. To install the software:


1. Insert the CD-ROM into your CD drive.
2. Select the EtherGuard or WiNeTool folder, then double-click the “setup.exe” file under the folder. A “Welcome” screen will open.




3. Click “Next.”




4. Click “Yes” to agree to the license statement. An information screen will open showing the minimum system requirements needed to run the program.




5. If your system meets the requirements, click “Next.”



6. On the “Choose Destination Location” screen, click “Browse” to install the program files into a folder other than the default, or click “Next” to install to the default folder shown on the screen.



7. Choose the location where the program icons will be located and click "Next."



8. Check the "To launch EtherGuard" box and click "Finish" to complete the installation and launch the EtherGuard program.


The EtherGuard program may also be started by clicking "Start/Programs/EtherGuard/EtherGuard." The program will start and then run in the background. A globe icon will appear on the toolbar (see the figure on the next page). Double-click the icon to bring the program to the foreground.

See the following section for EtherGuard configuration instructions, or go to "WiNeTool" on page 23 for WiNeTool configuration instructions.


EtherGuard

EtherGuard monitors both outgoing and incoming data to protect your children, your employees, and yourself against network and Internet intrusions.


1. The program opens with the EtherGuard “Welcome” screen.



2. The screen contains four main menu items. The same menu items are also available from the EtherGuard toolbar icon. The EtherGuard icon on the toolbar will change should the EtherGuard program detect an attempt to attack the network.
3. The “Enable” and “Disable” menu items allow you to start and stop the EtherGuard program, “Statistic” provides network traffic information, and “Advance” sets advanced filter controls. Access to the Enable, Disable, and Advance menu items may be password restricted. To prevent unauthorized changes to the EtherGuard settings, you should set a password. Click “Help.” A menu will open.



4. Click “Modify Password.”



The 'Modify Password' dialog box has a blue title bar. It contains three text input fields labeled 'Original Password:', 'New Password:', and 'Confirm Password:'. At the bottom, there are two buttons: 'OK' with a green checkmark icon and 'Cancel' with a red X icon.


5. The default EtherGuard password setting is blank (no password required) so enter your password in the “New Password” field and then again in the “Confirm Password” field. Click “OK.”
6. As you attempt to open each menu item, enter your password if required.



The 'Input Password' dialog box has a blue title bar. It contains a single text input field labeled 'Password:'. At the bottom, there are two buttons: 'OK' with a green checkmark icon and 'Cancel' with a red X icon.

7. Click “Enable” or “Disable” to switch the program on and off.

8. Click “Statistic” to view possible intruder activity.



9. The ‘Statistic Information’ screen indicates the intruder’s IP address and the type of attack that was attempted.
10. Click “Advance” to set advanced filter controls. The “Filter Items Setting I” screen will open.




11. Checking “Name for Site” enables the filter function.

12. Sites whose names include words added to this list will be blocked. Enter a web address as a host name, e.g. `www.yahoo.com`, or just add a keyword, e.g. `yahoo`. Click the “Add” button. You may add up to 20 sites. To delete an address, select it in the “Filter List” and click “Delete.”


Note: When you input a site name, do not include “`http://`.”

13. Click the “Setting II” button.


14. Check the box in the “Filter Items II” section to enable the desired filter(s).




15. The IP address page allows you to filter by IP address. Add up to six numeric (e.g., `192.168.111.123`) IP addresses to the IP Filter List.



16. You may also filter up to 20 specified TCP and UDP ports (see figures above and below). For a full list of ports and the services that run on them, see www.iana.org/assignments/port-numbers.



17. Check the boxes on the “Protocol Filter” page to block particular protocols.




18. Once you have enabled the filters and completed your settings, click “Close.”
19. Close and re-launch your web browser to allow the new settings to take affect.

WiNeTool

WiNeTool provides network adapter information, generates specified packets, captures packets, and analyzes network traffic. WiNeTool also generates wake-up packets.

The installation program will place an icon in the toolbar. Double-click the icon to open the program. The WiNeTool program may also be started by clicking “Start/Programs/WiNeTool/WiNeTool.”

You will be asked to choose the network adapter to be analyzed.




If no choice is made, the default adapter will be chosen after 10 seconds. WiNeTool will then run in the background and an icon will appear on the toolbar.



Double-click the icon to bring the program to the foreground.

Configuration




The WiNeTool opens with the “Configuration” page. Here you may view the current configuration for this adapter. If required, click “Help” for access to the HTML help files.

Configuration		TX/RX Information	
MAC Address	The Media Access Control Address of this adapter.	Transmit One Collision	Number of frames that were not transmitted as they encountered one collision.
Link Speed	The speed of the connection (10 or 100 Mbps).	Transmit Underrun	The network adapter starts transmitting a packet as soon as it receives the first data block from the CPU. If the CPU does not deliver the rest of the packet data in time, a transmit underrun error occurs.
Driver Name	Name of the current device driver.	Transmit Deferred	Number of frames that were deferred before transmission due to activity on the link.

IP Address	The IP Address of this adapter.	Receive Error	Number of errors in reception.
Computer Name	The name of this computer.	Receive Error Alignment	Number of alignment errors, in which the frame does not contain an integral number of octets.
		CRC Error	Cyclic Redundancy Code Error.
Activity			
Packets Transmitted	Number of packets transmitted by the adapter.	Packets Received	Number of packets received by the adapter.


Send Packet

Sends fixed length packets in the default pattern at one of two speeds, Normal mode or Turbo mode. The value of Pks/s (packets per second) depends on the computer's performance.



H: M: S:	Indicates hours, minutes, seconds of time the WiNeTool has been sending packets.
Reset, OFF, ON	Resets, Stops, Starts sending packets.
Normal Mode	Click on the flash to change the mode between normal and turbo.
Statistics	TX Count: Number of transmitted packets Pks/s: Transmitted packets per second.
Setting Pattern	Click this button to open the advanced settings "Packet Generator" dialog box. (See the following page for instructions.)

Packet Generator




The “Packet Generator” allows you to send packets with a defined mode, length, and pattern.

Send Mode	If “Continue” is checked, the WiNeTool will keep sending packets until “OFF” is pressed on the main “Send Packet” screen.
Interval	Sets the interval between two contiguous packets.
Hex	Allows you to define the pattern and length to suit your application frame format.
Now packet Size	Shows the current packet size.

The arrow icons allow you to navigate forward and backward through the pages.


Send ACPI Packet



Sends an ACPI (Advanced Configuration and Power Interface) packet to wake up a sleeping computer.

Magic Packet	Input the MAC address of the sleeping computer you wish to wake up and click “Send.” Click “Clear” to clear the box and input a new address.
Wakeup Frame	Input the IP address of the sleeping computer you wish to wake up and click “Send.” Click “Clear” to clear the box and input a new figure.


Receive Packet - Gauge




ON/OFF power socket icon	Starts/Stops the real-time monitor function.
Packets/S Max.	Number of received packets per second.
Utilization %	Percentage of bandwidth used.
Errors /S	Number of CRC errors generated per second.
Analysis button	Advanced real-time capture and analysis settings.

Capture Console Toolbar

Click “Analysis” to open the capture console.




Start	Starts the capture function. You must set filters using the “Set” button before capturing.
Stop	Stops the capture function.
Stop & View	Stops the capture function and opens the “Analysis Packet” screen.
View	Opens the “Analysis Packet” screen.
Set	Opens the “Filter Setting” screens.

Filter Setting - MAC Address


Sets the MAC address of computers (stations) as filtering criteria. You must enter a 12 digit MAC address in the Station 1 and Station 2 fields (or enter “any”). Click on the arrow symbols in the direction column to set the direction of the packet flow to be captured.

Filter Setting - IP Address




Sets the IP address of computers (stations) as filtering criteria. Enter an IP address in the Station 1 and Station 2 fields (or enter "any"). Click on the arrow symbols in the direction column to set the direction of the packet flow to be captured.

Filter Setting - Protocol



Sets protocols as filtering criteria.


Filter Setting - Pattern



Sets the pattern and position as filtering criteria.


Note: In the above example, “11 22 33 44 55 66 99 DD” is at byte position 0x23. Therefore, WiNeTool will only capture a packet with the same pattern (11 22 33 44 55 66 99 DD) in the same position.

Filter Setting - Buffer Size



Sets the hard disk buffer size for captured packets. The default is 300 Kilobytes.

Packet Analysis




The Packet Analysis screen features three windows:

The top window gives basic information on captured packets, including the layer to which the packets belong.

The center window shows detailed data on each layer.

The lower window shows the HEX and ASCII code related to the selected data in the top window.

Receive Packet - Detail



The “Detail” page provides detailed network information and shows the packet size distribution, i.e, number of Bytes with a size up to 64 Bytes, number of Bytes with a size of 65 to 127 Bytes, etc.

TROUBLESHOOTING

PCI Compatibility

Early PCI BIOS versions do not properly support the PCI specifications and may “hang” when a network card driver tries to load. If this occurs, make sure your BIOS correctly supports the PCI Local Bus Specifications (v2.0 or later) and upgrade your computer’s BIOS to the latest version.

Some PCI computers are not self-configuring and require you to perform some or all of the following functions by motherboard jumper changes and/or BIOS Setup program configuration:

- Verify that the PCI slot is an enabled bus master slot and not a slave PCI slot. The network card must be installed in a PCI bus master slot. Modern Windows-compatible motherboards generally support bus masters in all PCI slots, so you should be able to place the Barricade PCI in any slot. In some computers the PCI slot must be configured to enable bus mastering. Refer to your PC’s manual and check the PCI BIOS Setup program to be sure the PCI slot is an enabled bus master slot.
- In some computers, you may be required to disable Plug-and-Play in the BIOS Setup program if resources are not properly assigned between the network card and other installed cards.

- Older computers may require you to reserve interrupts and memory addresses for installed ISA cards to prevent PCI cards from using the same settings. Refer to your PC's manual and check the PCI BIOS setup program configuration options for ISA cards.
- Make sure the PCI slot is configured to support INTA.
- Ensure that INTA for the slot is assigned to a free interrupt (IRQ) number.
- Check the BIOS setup program's PCI parameters for the slot where the network card is installed. Ensure that the slot is configured for level-triggered interrupts instead of edge-triggered interrupts. An example of typical PCI parameters follows:

PCI Slot #:	<i>(slot number where the network card is installed)</i>
Master:	Enabled
Slave:	Enabled
Latency Timer:	40 (range is 20 to 255)
Interrupt Type:	Level-Triggered
Interrupt Number:	<i>(choose any number the BIOS setup supplies that does not conflict with another installed card)</i>

Note: The wording of these parameters varies with different computers, and not all parameters may be configurable.

Always consult your computer manual for information on changing motherboard jumper settings and BIOS setup program parameters for use with PCI network cards. If you set a motherboard jumper and modify the computer's BIOS setup, make sure the jumper and BIOS settings match.

Solutions for Common Problems

Problems are often caused by cabling errors, conflicts with other devices installed in the same computer, or software that has been configured incorrectly. If you encounter a problem with the network card, use the following checklists to identify and correct the problem.

Network Card Installation Problems

If your computer cannot find the Barricade PCI card, or the network driver does not install correctly, check the following items before contacting SMC Technical Support.

- Make sure the card is securely seated in the PCI slot. Check for any hardware problems, such as physical damage to the card's edge connector.
- Try the card in another PCI bus master slot. If this fails, test with another Barricade PCI card that is known to operate correctly.
- Check for resource conflicts in the PCI configuration. See section "PCI Compatibility" in this chapter.
- Make sure your computer is using the latest BIOS available.
- If there are other network cards in the computer, they may be causing conflict. Remove all other cards from the computer and test the Barricade PCI card separately.
- Check for a defective computer or PCI bus by trying the network card in another computer that is known to operate correctly.

Network Connection Problems

There may be a network connection problem if the LED on the card's bracket does not light, or if you cannot access any network resources from the computer. Check the following items before contacting SMC Technical Support.

- Be sure you are using Category 5 cable for 100 Mbps connections, and that the length of any cable does not exceed 100 m (328 ft).
- Inspect all network cables and connections. Make sure the network cable is securely attached to the card's connector.
- Make sure the correct network card driver is installed for your operating system. If necessary, try reinstalling the driver.
- Make sure the computer and other network devices are receiving power. If you suspect a power outlet to be faulty, plug another device into it to verify that it is working.
- If the network card's speed or duplex mode has been configured manually, check that it matches that of the attached network device port. Note that it is recommended to set the card to auto-negotiation when installing the network driver.
- The port on the network device that the card is attached to may be defective. Try using another port on the device.
- If you cannot access a Windows or NetWare service on the network, check that you have enabled and configured the service correctly. If you cannot connect to a particular server, ensure that you have access rights and a valid ID and password.

TROUBLESHOOTING

- If you cannot access the Internet, be sure you have configured your system for TCP/IP.

CABLE SPECIFICATIONS

Cable and Specifications

Cable Types and Specifications			
Cable	Type	Max. Length	Connector
10BASE-T	Cat. 3, 4, 5 100-ohm UTP	100 m (328 ft)	RJ-45
100BASE-TX	Cat. 5 100-ohm UTP	100 m (328 ft)	RJ-45

Twisted-Pair Cable and Pin Assignments


Do **NOT** plug a phone jack connector into any RJ-45 port. Use only twisted-pair cables with RJ-45 connectors that conform with FCC standards.

For 10BASE-T/100BASE-TX connections, a twisted-pair cable must have two pairs of wires. Each wire pair is identified by two different colors. For example, one wire might be red and the other red with white stripes. Also, an RJ-45 connector must be attached to both ends of the cable.

Caution: Each wire pair must be attached to the RJ-45 connector in a specific orientation.

CABLE SPECIFICATIONS

The figure below illustrates how the pins on the RJ-45 connector are numbered. Be sure to hold the connectors in the same orientation when attaching the wires to the pins.



With 10BASE-T/100BASE-TX cable, pins 1 and 2 are used for transmitting data, and pins 3 and 6 for receiving data. The “+” and “-” signs in the tables below are used to represent the polarity of the wires that make up each wire pair.

RJ-45 Pin Assignments	
Pin	Assignment
1	Tx+
2	Tx-
3	Rx+
6	Rx-

SPECIFICATIONS

Port

1 RJ-45 for 10BASE-T and 100BASE-TX

Host Interface

PCI Bus compliant to PCI spec. 2.2

LED

Link, Speed, Activity

Data Bus Access

32-bit bus mastering

Size (without bracket)

120 x 43 mm (4.72 x 1.69 in)

Weight

43.68 g (1.54 oz)

Power Requirements

5 VDC, 125 mA (typical)

Temperature

Operating: 0 to 55 °C (32 to 131 °F)

Storage: -20 to 65 °C (-4 to 149 °F)

Humidity, non-condensing

10% to 90%

Standards

IEEE 802.3 10BASE-T

IEEE 802.3u 100BASE-TX

IEEE 802.3x 100BASE-TX Flow Control support

IEEE 802.1p/Q Quality of Service (QoS)

PCI bus V 2.2, ACPI

OnNow/PC 98, PC 99

DMI 2.0, Wired for Management 2.0

SPECIFICATIONS

Compliances

FCC Class B

VCCI Class B

CE Mark

CISPR 22 Class B

Warranty

Limited lifetime

NetWare ODI Drivers

Novell NetWare 3.1X to 6.0

Netware Lan WorkPlace

Novell DOS Client

Novell Lan Analyzer

Server 3.1x to 5.x

Unix Drivers

Linux

FreeBSD

SCO Unix 5.0x, 7.x

NDIS Drivers

Windows 95 OSR2

Windows 98

Windows 2000

Windows ME

Windows XP

Windows NT 3.51, 4.0

Microsoft Lan Manager

IBM LAN Server

IBM LAN Support

DEC PATHWORKS

Windows for Workgroups 3.11

Packet Drivers

FTP PC/TCP

NCSA TCP/IP

FOR TECHNICAL SUPPORT, CALL:

From U.S.A. and Canada (24 hours a day, 7 days a week)
(800) SMC-4-YOU; (949) 679-8000; Fax: (949) 679-1481
From Europe (8:00 AM - 5:30 PM UK Time)
44 (0) 118 974 8700; Fax: 44 (0) 118 974 8701

INTERNET

E-mail addresses:
techsupport@smc.com
european.techsupport@smc-europe.com

Driver updates:

http://www.smc.com/index.cfm?action=tech_support_drivers_downloads

World Wide Web:

<http://www.smc.com/>
<http://www.smc-europe.com/>

For Literature or Advertising Response, Call:

U.S.A. and Canada:	(800) SMC-4-YOU;	Fax (949) 679-1481
Spain:	34-93-477-4935;	Fax 34-93-477-3774
UK:	44 (0) 118 974 8700;	Fax 44 (0) 118 974 8701
France:	33 (0) 41 38 32 32;	Fax 33 (0) 41 38 01 58
Italy:	39 02 739 12 33;	Fax 39 02 739 14 17
Benelux:	31 33 455 72 88;	Fax 31 33 455 73 30
Central Europe:	49 (0) 89 92861-0;	Fax 49 (0) 89 92861-230
Switzerland:	41 (0) 1 9409971;	Fax 41 (0) 1 9409972
Nordic:	46 (0) 868 70700;	Fax 46 (0) 887 62 62
Northern Europe:	44 (0) 118 974 8700;	Fax 44 (0) 118 974 8701
Eastern Europe:	34 -93-477-4920;	Fax 34 93 477 3774
Sub Saharan Africa:	27-11 314 1133;	Fax 27-11 314 9133
North Africa:	34 93 477 4920;	Fax 34 93 477 3774
Russia:	7 (095) 290 29 96;	Fax 7 (095) 290 29 96
PRC:	86-10-6235-4958;	Fax 86-10-6235-4962
Taiwan:	886-2-2659-9669;	Fax 886-2-2659-9666
Asia Pacific:	(65) 238 6556;	Fax (65) 238 6466
Korea:	82-2-553-0860;	Fax 82-2-553-7202
Japan:	81-3-5645-5715;	Fax 81-3-5645-5716
Australia:	61-2-8875-7887;	Fax 61-2-8875-7777
India:	91-22-8204437;	Fax 91-22-8204443

If you are looking for further contact information, please visit www.smc.com or www.smc-europe.com.



38 Tesla
Irvine, CA 92618
Phone: (949) 679-8000

Model Number: SMC1255TX
Part No: 150000026800A E122002-R02